

Manual Supplement

Manual Title: BT510 Users
Print Date: May 2014
Revision/Date: 1, 8/15

Supplement Issue: **2**
Issue Date: 9/19
Page Count: 2

This supplement contains information necessary to ensure the accuracy of the above manual.

Change #1, 688, 721

Replace page 6-9, **Parts and Accessories**, with:

Parts and Accessories

Table 6-1 lists the user-replaceable parts and accessories. To order replacement parts or additional accessories, contact your nearest Fluke Service Center. Check with your local vendor for list of parts that can be ordered in your country. See the “Contact Fluke” section.


Table 6-1. Parts and Accessories

Item No.	Description	Fluke Part Number	Quantity
①	BTL10, Basic Test Lead	4542264	1
②	TL175, TwistGuard™ Test Leads	3521976	1
③	BTL_A, Voltage/Current Probe Adapter	4542258	1
④	BP500, 7.4 V 3000 mAh Lithium-ion battery	4398817	1
⑤	BC500, 18 V dc charger with power cord and International connector set	4542299	1
⑥	Standard mini-b USB cable (cable length: 1 m)	4499448	1
⑦	BCR, Zero calibration board	4497419	1
⑧	Shoulder strap	4490029	1
⑨	Belt strap	4490316	1
⑩	Magnetic plate	4329190	1
⑪	C500S Soft carrying case, small	4462874	1
⑫	Spare fuse	943121	2
⑬	Safety Sheet	4453942	1
⑭	Warranty card	2396000	1
⑮	Quick Reference Guide	4453956	1
⑯	FlukeView® Battery (CD) containing USB driver and manuals in all languages	4529552	1
⑰	BT-500 Probe-Tip, Replacement Probe tips with Red covers	4397118	2
⑱	BT-500 Probe-Tip, Replacement Probe tips with Black covers	4397107	2
⑲	BT-500 Probe-Tip, Replacement Probe tips connector	4408615	2

Change #2, 721

On page 1-3, **Table 1-1. Standard Equipment**, replace Items 6 and 7 with:

⑥	BC500, 18 V dc charger with power cord and International connector set	1
⑦	Probe-Tip, Replacemnet Probe tips with covers.	1

On page 1-7, **Table 1-2. Symbols**, remove .

On page 1-4, replace **Figure 1-1. Standard Equipment**, with:

